



THIS MANUAL IS AVAILABLE FOR FREE
COMPLIMENTS OF

BUYMEBUYME.COM


**TO ORDER THIS PRODUCT, PLEASE CALL TOLL-FREE
1-877-992-8963 OR VISIT WWW.BUYMEBUYME.COM**

Signal Booster Installation Guide

To install the Signal Booster, perform the following steps and refer to the drawing below:

1. Connect the cable from your cable service provider or antenna (cable in) to the Signal Input on the Signal Booster. *(In typical installations, the input cable is already connected to the television or VCR. Disconnect this cable and connect it to the Signal Input on the Signal Booster).*
2. Connect the Signal Output on the Signal Booster to the television or VCR input using the supplied 6 foot coaxial cable.
3. Use the other 6 foot coaxial cable to connect the ac adapter to the Power 12 Vdc connector on the Signal Booster.
4. Plug the ac adapter into a convenient wall outlet. The lighted, green LED confirms that power is correctly applied.

You can mount the Signal Booster to any suitable indoor surface using the screws provided, or it may lay flat.



If You Need Help

If you need assistance while working with the Signal Booster, call Motorola's Customer Service and Technical Support Center at 1-877-466-8646.



LIMITED WARRANTY – SIGNAL BOOSTER (U.S.A. and Canada)

Motorola, Inc., Broadband Communications Sector (“Motorola”)
Transmission Network Systems
101 Tournament Drive
Horsham, PA 19044

What is covered? Motorola warrants to the original customer that the Signal Booster Broadband Drop Amplifier provided in this package (the “Product”), will be free from defects in materials and workmanship under normal use. This warranty shall not apply: (i) to any Product subjected to accident, misuse, neglect, alteration, Acts of God, improper handling, improper transport, improper storage, improper use or application, improper installation, improper testing or unauthorized repair; or (ii) to cosmetic problems or defects which result from normal wear and tear under ordinary use, and do not affect the performance or use of the Product. This warranty applies only to a Product that is manufactured by Motorola and identified by the General Instrument (“GI”) or Motorola trademark, trade name or Signal Booster identification logo affixed to the Product. EXCEPT AS EXPRESSLY STATED IN THIS PARAGRAPH, THERE ARE NO WARRANTIES OF ANY KIND RELATING TO THE PRODUCT, EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR THE WARRANTY AGAINST INFRINGEMENT PROVIDED IN THE UNIFORM COMMERCIAL CODE. Some states do not allow for the exclusion of implied warranties, so the above exclusion may not apply to you.

What additional provisions should I be aware of? Because it is impossible for Motorola to know the purposes for which you acquired this Product or the uses to which you will put this Product, you assume full responsibility for the selection of the Product for its installation and use. While every reasonable effort has been made to insure that you will receive a Product that you can use and enjoy, Motorola does not warrant that the functions of the Product will meet your requirements or that the operation of the Product will be uninterrupted or error-free. Motorola is not responsible for problems caused by the interaction of the Product with any other equipment, hardware or software.

How long does this Limited Warranty last? The Limited Warranty for the Product continues for a period of one (1) year from the date of purchase from an authorized Motorola reseller.

What you must do to obtain warranty service. To take advantage of this Limited Warranty or to obtain technical support, you must call the Motorola toll-free phone number (below). Motorola’s sole and exclusive obligation shall be to repair or replace any Product that does not meet Motorola’s Limited Warranty. All warranty claims must be made within the applicable warranty period of one (1) year. THIS WARRANTY IS VOID IF THE PRODUCT IS DAMAGED.

THESE ARE YOUR SOLE AND EXCLUSIVE REMEDIES for any and all claims that you may have arising out of or in connection with this Product, whether made or suffered by you or another person and whether based in contract or tort.

IN NO EVENT SHALL MOTOROLA BE LIABLE TO YOU OR ANY OTHER PARTY FOR ANY DIRECT, INDIRECT, GENERAL, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR OTHER DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION OR ANY OTHER PECUNIARY LOSS), OR FROM ANY BREACH OF WARRANTY, EVEN IF MOTOROLA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. (Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.) IN NO CASE SHALL MOTOROLA’S LIABILITY EXCEED THE AMOUNT YOU PAID FOR THE PRODUCT.

This warranty is governed by the laws of the Commonwealth of Pennsylvania, excluding its conflict of laws principles.

Motorola’s toll-free number is 1-877-466-8646.